



FR. →

Ref #	Part Number	Qty	Description
1	16271-ZE1-000	1	GASKET, ELBOW (Honda Code 1427194).
2	17210-ZE1-505	1	ELEMENT, AIR CLEANER (DUAL) (Honda Code 5247408).
2	17210-ZE1-822	1	ELEMENT, AIR CLEANER (DUAL) (Honda Code 2893881).
3	17218-ZE1-821	1	FILTER (OUTER) (Honda Code 2535029).
4	17230-ZE1-820	1	COVER, AIR CLEANER (DUAL) (Honda Code 1445790).
5	17232-891-000	1	GROMMET, AIR CLEANER (Honda Code 0999763).
6	17235-ZE1-831	1	NOSE, MUFFLER (Honda Code 4755260).
7	17238-ZE7-010	2	COLLAR, AIR CLEANER (Honda Code 2455673).
8	17239-ZE1-000	1	COLLAR B, AIR CLEANER (Honda Code 1427533).
9	17410-ZE1-020	1	ELBOW, AIR CLEANER (Honda Code 2481653).
10	90325-044-000	2	WINGNUT, TOOL BOX SETTING (Honda Code 0127720).
11	94050-06000	2	NUT, FLANGE (6MM) (Honda Code 0471623).
12	95701-06020-00	1	BOLT, FLANGE (6X20) (Honda Code 2105815).





FR. 

Ref #	Part Number	Qty	Description
1	12209-ZH8-003	1	SEAL, VALVE STEM (Honda Code 6854335).
1	12209-ZL0-003	1	SEAL, VALVE STEM (Honda Code 4742748).
2	14100-ZL0-000	1	CAMSHAFT ASSY. (Honda Code 4742920).
3	14410-ZE1-010	2	ROD, PUSH (Honda Code 3352655).
4	14431-ZE1-000	2	ARM, VALVE ROCKER (Honda Code 1426824).
5	14451-ZE1-013	2	PIVOT, ROCKER ARM (Honda Code 4300901).
6	14568-ZE1-000	1	SPRING, WEIGHT RETURN (Honda Code 1426907).
7	14711-ZF1-000	1	VALVE, IN. (Honda Code 3683455).
8	14721-ZF1-000	1	VALVE, EX. (Honda Code 3683463).
9	14731-ZL0-000	2	LIFTER, VALVE (Honda Code 4742946).
10	14751-ZF1-000	2	SPRING, VALVE (Honda Code 3683489).
11	14771-ZE1-000	1	RETAINER, IN. VALVE SPRING (Honda Code 1426980).
12	14773-ZE1-000	1	RETAINER, EX. VALVE SPRING (Honda Code 1426998).
13	14781-ZE1-000	1	ROTATOR, VALVE (Honda Code 1427004).
14	14791-ZE1-010	1	PLATE, PUSH ROD GUIDE (Honda Code 1899947).
15	90012-ZE0-010	2	BOLT, PIVOT (8MM) (Honda Code 1756964).
16	90206-ZE1-000	2	NUT, PIVOT ADJ. (Honda Code 1431287).




FR. 

Ref #	Part Number	Qty	Description
1	16010-ZE1-812	1	GASKET SET (Honda Code 3477171).
2	16011-ZE0-005	1	VALVE SET, FLOAT (Honda Code 1441476).
3	16013-ZE0-005	1	FLOAT SET (Honda Code 1441492).
4	16015-ZE0-831	1	CHAMBER SET, FLOAT (Honda Code 2455608).
4	16015-ZE1-811	1	CHAMBER SET, FLOAT (Honda Code 2464287).
5	16016-ZH7-W01	1	SCREW SET (Honda Code 4219879).
6	16024-ZE1-811	1	SCREW SET, DRAIN (Honda Code 1672187).
7	16028-ZE0-005	1	SCREW SET B (Honda Code 1441518).
8	16044-ZE0-005	1	CHOKE SET (Honda Code 1441526).
9	16100-ZL0-W51	1	CARBURETOR ASSY. (BE64B B) (Honda Code 5148101).
10	16124-ZE0-005	1	SCREW, THROTTLE STOP (Honda Code 1441559).
11	16166-ZL0-000	1	NOZZLE, MAIN (Honda Code 4743050).
12	16173-001-004	1	GASKET, FUEL STRAINER CUP (Honda Code 0005652).
13	16211-ZL0-000	1	INSULATOR, CARBURETOR (Honda Code 4743068).
14	16212-ZH8-800	1	GASKET, INSULATOR (Honda Code 3683547).
15	16220-ZE1-020	1	SPACER, CARBURETOR (Honda Code 2534055).
16	16221-ZH8-801	1	GASKET, CARBURETOR (Honda Code 4725289).
17	16610-ZE1-000	1	LEVER, CHOKE (STD) (Honda Code 1440114).
18	16953-ZE1-406	1	LEVER, VALVE (Honda Code 5167358).
18	16953-ZE1-811	1	LEVER, VALVE (Honda Code 1819986).
18	16953-ZE1-812	1	LEVER, VALVE (Honda Code 5140876).
19	16954-ZE1-811	1	PLATE, LEVER SETTING (Honda Code 1807791).
19	16954-ZE1-812	1	PLATE, LEVER SETTING (Honda Code 5148135).
19	16954-ZE1-812	1	PLATE, LEVER SETTING (Honda Code 5148135).
20	16956-ZE1-811	1	SPRING, VALVE LEVER (Honda Code 1807809).
21	16957-ZE1-812	1	GASKET, VALVE (Honda Code 3440708).
22	16967-ZE0-811	1	CUP, FUEL STRAINER (Honda Code 1441583).
23	93500-03006-0H	2	SCREW, PAN (3X6) (Honda Code 0561654).
23	93500-03008-0G	2	SCREW, PAN (3X8) (Honda Code 0420505).
24	94305-20122	1	PIN, SPRING (2X12) (Honda Code 1441591).
25	99101-ZH8-0680	1	JET, MAIN (#68) (Optional). (Honda Code 5519996).
25	99101-ZH8-0700	1	JET, MAIN (#70) (Optional). (Honda Code 5427505).
25	99101-ZH8-0720	1	JET, MAIN (#72) (Honda Code 6056139).
26	99204-ZA0-0450	1	JET SET, PILOT (#45) (Honda Code 2060465).











FR. →

Ref #	Part Number	Qty	Description
2	16500-ZH8-822	1	CONTROL ASSY. (REMOTE) (Honda Code 5904669).
2	16500-ZH8-823	1	CONTROL ASSY. (REMOTE) (Honda Code 6147755).
2	16500-ZH8-823	1	CONTROL ASSY. (REMOTE) (Honda Code 6147755).
4	16551-ZL0-000	1	ARM, GOVERNOR (Honda Code 4743084).
5	16555-ZE1-000	1	ROD, GOVERNOR (Honda Code 1427319).
6	16561-ZL0-000	1	SPRING, GOVERNOR (Honda Code 4743092).
7	16562-ZE1-020	1	SPRING, THROTTLE RETURN (Honda Code 1950625).
8	16571-ZH8-000	1	LEVER, CONTROL (Honda Code 3683596).
8	16571-ZH8-020	1	LEVER, CONTROL (Honda Code 6145338).
9	16574-ZE1-000	1	SPRING, LEVER (Honda Code 1427384).
10	16575-ZH8-000	1	WASHER, CONTROL LEVER (Honda Code 3683604).
11	16576-891-000	1	HOLDER, CABLE (Honda Code 0800466).
12	16578-ZE1-000	1	SPACER, CONTROL LEVER (Honda Code 1427400).
13	16580-ZH8-811	1	BASE, CONTROL (Honda Code 4725321).
13	16580-ZH8-812	1	BASE, CONTROL (Honda Code 5924451).
13	16580-ZH8-813	1	BASE, CONTROL (REMOTE) (Honda Code 6145346).
14	16584-883-300	1	SPRING, CONTROL ADJUSTING (Honda Code 0636431).
15	16592-ZE1-810	1	SPRING, CABLE RETURN (Honda Code 1445774).
17	90013-883-000	2	BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
18	90015-ZE5-010	1	BOLT, GOVERNOR ARM (Honda Code 2418671).
19	90114-SA0-000	1	NUT, SELF-LOCK (6MM) (Honda Code 1410182).
22	93500-05016-0A	1	SCREW, PAN (5X16) (Honda Code 0145557).
23	93500-05025-0H	1	SCREW, PAN (5X25) (Honda Code 0374702).
24	94050-06000	1	NUT, FLANGE (6MM) (Honda Code 0471623).




Ref #	Part Number	Qty	Description
2	11300-ZE1-641	1	COVER ASSY., CRANKCASE (U-TYPE) (Honda Code 4731568).
3	11381-ZH8-801	1	GASKET, CASE COVER (NON-ASBESTOS) (Honda Code 4723144).
3	11381-ZL0-000	1	GASKET, CASE COVER (Honda Code 4917720).
4	15600-ZE1-003	1	CAP ASSY., OIL FILLER (Honda Code 4500146).
5	15600-ZG4-003	1	CAP ASSY., OIL FILLER (Honda Code 4497921).
6	15625-ZE1-003	2	GASKET, OIL FILLER CAP (Honda Code 4497947).
7	91202-883-005	1	OIL SEAL (25X41X6) (Honda Code 0636936).
8	94301-08140	2	PIN A, DOWEL (8X14) (Honda Code 0069310).
9	95701-08032-00	6	BOLT, FLANGE (8X32) (Honda Code 2751725).
10	96100-62050-00	1	BEARING, RADIAL BALL (6205) (Honda Code 0636977).




FR. →

Ref #	Part Number	Qty	Description
2	13310-ZL0-600	1	CRANKSHAFT (Q-TYPE) (Honda Code 4742862).
8	90745-ZE1-600	1	KEY (4.78X4.78X38) (Honda Code 1441062).




FR. →

Ref #	Part Number	Qty	Description
1	12000-ZL0-810	1	CYLINDER ASSY. (OIL ALERT) (Honda Code 4742722).
1	12000-ZL0-811	1	CYLINDER ASSY. (Honda Code 6841050).
2	15510-ZE1-023	1	SWITCH ASSY., OIL LEVEL (Honda Code 5262605).
2	15510-ZE1-023	1	SWITCH ASSY., OIL LEVEL (Honda Code 5262605).
2	15510-ZE1-033	1	SWITCH ASSY., OIL LEVEL (Honda Code 5962063).
2	15510-ZE1-033	1	SWITCH ASSY., OIL LEVEL (Honda Code 5962063).
3	16506-ZL0-000	1	GOVERNOR ASSY. (Honda Code 4743076).
4	16531-ZE1-000	1	SLIDER, GOVERNOR (Honda Code 1427251).
5	16541-ZE1-000	1	SHAFT, GOVERNOR ARM (Honda Code 1427277).
6	90131-ZE1-000	2	BOLT, DRAIN PLUG (Honda Code 1431246).
7	90451-ZE1-000	1	WASHER, THRUST (6MM) (Honda Code 2413862).
8	90601-ZE1-000	2	WASHER, DRAIN PLUG (10.2MM) (Honda Code 1436583).
9	90602-ZE1-000	1	CLIP, GOVERNOR HOLDER (Honda Code 2456697).
10	91001-ZF1-003	1	BEARING, RADIAL BALL (6205) (Honda Code 3684248).
11	91202-883-005	1	OIL SEAL (25X41X6) (Honda Code 0636936).
12	91353-671-003	1	O-RING (13.5X1.5) (ARAI) (Honda Code 0949883).
13	94050-10000	1	NUT, FLANGE (10MM) (Honda Code 0483867).
14	94101-06800	2	WASHER, PLAIN (6MM) (Honda Code 0345900).
15	94251-08000	1	PIN, LOCK (8MM) (Honda Code 0115527).
16	95701-06012-00	2	BOLT, FLANGE (6X12) (Honda Code 2105799).




FR. 



Ref #	Part Number	Qty	Description
1	12204-ZE1-306	1	GUIDE, VALVE (OS) (Optional). (Honda Code 4165874).
2	12205-ZE1-315	1	GUIDE, EX. VALVE (OS) (Optional). (Honda Code 1899848).
3	12210-ZL0-000	1	CYLINDER HEAD (Honda Code 4742755).
4	12216-ZE5-300	1	CLIP, VALVE GUIDE (Honda Code 2399780).
5	12251-ZL0-003	1	GASKET, CYLINDER HEAD (Honda Code 4742763).
6	12310-ZE1-010	1	COVER, HEAD (Honda Code 4725248).
7	12391-ZE1-000	1	GASKET, CYLINDER HEAD COVER (Honda Code 1426527).
8	15721-ZH8-000	1	TUBE, BREATHER (Honda Code 3683497).
9	90013-883-000	4	BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
10	90043-ZE1-020	2	BOLT, STUD (6X109) (Honda Code 4588323).
11	90047-ZE1-000	2	BOLT, STUD (8X32) (Honda Code 1431097).
12	94301-10160	2	PIN A, DOWEL (10X16) (Honda Code 0058206).
14	95723-08060-00	4	BOLT, FLANGE (8X60) (Honda Code 1436591).
15	98079-55846	1	SPARK PLUG (BPR5ES) (NGK) (Optional). (Honda Code 1672443).
15	98079-55855	1	SPARK PLUG (W16EPR-U) (DENSO) (Optional). (Honda Code 1672450).
15	98079-56846	1	SPARK PLUG (BPR6ES) (NGK) (Honda Code 1441112).
15	98079-56855	1	SPARK PLUG (W20EPR-U) (DENSO) (Honda Code 1441120).



Ref #	Part Number	Qty	Description
1	19610-ZL0-000ZA	1	COVER, FAN *NH246* (LOOSY GRAY) (Honda Code 4743159).
1	19610-ZL0-000ZB	1	COVER, FAN *R8* (BRIGHT RED) (Honda Code 4743167).
1	19610-ZL0-000ZD	1	COVER, FAN *NH1* (BLACK) (Honda Code 6139935).
3	19611-ZH8-810	1	PLATE, SIDE (OIL ALERT) (Honda Code 5891528).
3	19612-ZH8-810	1	PLATE, SIDE (STD) (Honda Code 3683778).
3	19612-ZH8-811	1	PLATE, SIDE (OIL ALERT) (Honda Code 5425624).
3	19612-ZH8-812	1	PLATE, SIDE (Honda Code 5891536).
6	19613-ZE1-010	1	CLAMP, CORD (Honda Code 5891544).
7	19630-ZH8-000	1	SHROUD (Honda Code 3683802).
8	32197-ZH8-003	1	SUB-HARNESS (Honda Code 4193082).
9	36100-ZE1-015	1	SWITCH ASSY., ENGINE STOP (Honda Code 2787869).
9	36100-ZH7-003	1	SWITCH ASSY., ENGINE STOP (Honda Code 5266184).
10	36101-ZE1-010	1	WIRE, STOP SWITCH (370MM) (Honda Code 3684032).
11	90013-883-000	6	BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
12	90022-888-010	1	BOLT, FLANGE (6X20) (CT200) (Honda Code 0671552).
13	34150-ZH7-003	1	ALERT UNIT, OIL (Honda Code 5858444).
15	95701-06008-00	1	BOLT, FLANGE (6X8) (Honda Code 2581353).



Ref #	Part Number	Qty	Description
1	13331-357-000	1	KEY, SPECIAL WOODRUFF (25X18) (Honda Code 0348433).
2	19511-ZE1-000	1	FAN, COOLING (Honda Code 1428051).
4	28451-ZL0-000	1	PULLEY, STARTER (Honda Code 4743233).
5	31100-ZE7-010	1	FLYWHEEL (STD) (Honda Code 5317417).
7	90201-878-003	1	NUT, SPECIAL (14MM) (Honda Code 0442038).




FR. 

Ref #	Part Number	Qty	Description
1	16854-ZH8-000	1	RUBBER, SUPPORTER (107MM) (Honda Code 3683646).
2	16955-ZE1-000	1	JOINT, FUEL TANK (Honda Code 1427459).
3	17510-ZE1-020ZA	1	TANK, FUEL *NH31* (MCKINLEY WHITE) (Honda Code 3683661).
3	17510-ZE1-020ZF	1	TANK, FUEL *NH1* (BLACK) (Honda Code 4212429).
4	17620-ZH7-023	1	CAP, FUEL FILLER (Honda Code 5344817).
5	17631-ZH7-003	1	GASKET, FUEL FILLER CAP (Honda Code 4608725).
7	91353-671-003	1	O-RING (13.5X1.5) (ARAI) (Honda Code 0949883).
8	94050-06000	2	NUT, FLANGE (6MM) (Honda Code 0471623).
9	95001-45003-60M	1	BULK HOSE, FUEL (4.5X3000) (4.5X140) (Honda Code 5137104).
10	95002-02080	2	CLIP, TUBE (B8) (Honda Code 0250647).
11	95701-06030-00	1	BOLT, FLANGE (6X30) (Honda Code 2401222).

No Artwork


Available

Ref #	Part Number	Qty	Description
	GASKET KIT		
	06111-ZL0-000	1	GASKET KIT (Honda Code 5148085).
1	11381-ZL0-000	1	GASKET, CASE COVER (Honda Code 4917720).
2	12251-ZL0-003	1	GASKET, CYLINDER HEAD (Honda Code 4742763).
3	12391-ZE1-000	1	GASKET, CYLINDER HEAD COVER (Honda Code 1426527).
4	15625-ZE1-003	1	GASKET, OIL FILLER CAP (Honda Code 4497947).
5	16212-ZH8-800	1	GASKET, INSULATOR (Honda Code 3683547).
6	16221-ZH8-801	1	GASKET, CARBURETOR (Honda Code 4725289).
7	18381-ZH8-800	1	GASKET, MUFFLER (Honda Code 3683745).





FR. 

Ref #	Part Number	Qty	Description
1	30500-ZE1-033	1	COIL ASSY., IGNITION (Honda Code 4589693).
2	30700-ZE1-013	1	CAP ASSY., NOISE SUPPRESSOR (Honda Code 3526837).
10	90121-952-000	2	BOLT, FLANGE (6X25) (Honda Code 0748111).






Ref #	Part Number	Qty	Description
1	87521-ZL0-000	1	EMBLEM (Honda Code 4743621).
1	87521-ZL0-010	1	EMBLEM (Honda Code 6762934).
3	87522-ZH9-000	1	LABEL, CAUTION (Honda Code 3684206).
4	87528-ZE1-810	1	MARK, CHOKE (Honda Code 1696715).
5	87532-ZB4-G60	1	MARK, OIL ALERT (GERMAN) (Honda Code 4425443).
5	87532-ZB4-H50	1	MARK, OIL ALERT (FRENCH) (Honda Code 4425450).
5	87532-ZH8-810	1	MARK, OIL ALERT (E) (Honda Code 4193355).




FR. 

Ref #	Part Number	Qty	Description
1	18310-ZL0-000	1	MUFFLER (Honda Code 4743100).
2	18315-ZE1-000	1	STAY, MUFFLER (Honda Code 1540830).
3	18320-ZF1-H51	1	PROTECTOR, MUFFLER (Honda Code 4640850).
5	18355-ZL0-000	1	ARRESTER, SPARK (Optional). (Honda Code 4743126).
6	18361-ZL0-000	1	NETTING, WIRE FLANGE (Honda Code 4743134).
7	18381-ZH8-800	1	GASKET, MUFFLER (Honda Code 3683745).
8	90016-ZE1-000	1	BOLT, FLANGE (6X13) (Honda Code 1541002).
9	90050-ZE1-000	4	SCREW, TAPPING (5X8) (Honda Code 1431105).
10	90055-ZE1-000	1	SCREW, TAPPING (4X6) (Honda Code 1431121).
11	94001-08000-0S	2	NUT, HEX. (8MM) (Honda Code 0167338).
12	95701-06012-00	1	BOLT, FLANGE (6X12) (Honda Code 2105799).



FR. 

Ref #	Part Number	Qty	Description
1	13010-ZL0-003	1	RING SET, PISTON (STD) (Honda Code 4742771).
1	13011-ZL0-003	1	RING SET, PISTON (OS 0.25) (Optional). (Honda Code 4742789).
1	13012-ZL0-003	1	RING SET, PISTON (OS 0.50) (Optional). (Honda Code 4742797).
1	13013-ZL0-003	1	RING SET, PISTON (0.75) (Optional). (Honda Code 4742805).
2	13101-ZL0-000	1	PISTON (STD) (Honda Code 4742813).
2	13102-ZL0-000	1	PISTON (OS 0.25) (Optional). (Honda Code 4742821).
2	13103-ZL0-000	1	PISTON (OS 0.50) (Optional). (Honda Code 4742839).
2	13104-ZL0-000	1	PISTON (0.75) (Optional). (Honda Code 4742847).
3	13111-ZE1-000	1	PIN, PISTON (Honda Code 1426584).
4	132A0-ZE1-000	1	ROD ASSY., CONNECTING (US 0.25) (Optional). (Honda Code 1441344).
4	13200-ZE1-010	1	ROD ASSY., CONNECTING (Honda Code 4725255).
5	90001-ZE1-000	2	BOLT, CONNECTING ROD (Honda Code 1431055).
6	90551-ZE1-000	2	CLIP, PISTON PIN (18MM) (Honda Code 2539120).



FR. →

Ref #	Part Number	Qty	Description
1	28400-ZH8-013ZA	1	STARTER ASSY., RECOIL *R8* (BRIGHT RED) (Honda Code 4193033).
1	28400-ZH8-013ZB	1	STARTER ASSY., RECOIL *NH1* (BLACK) (Honda Code 4193041).
2	28405-ZL0-000ZA	1	SPACER, RECOIL STARTER MOUNTING *NH1* (BLACK) (Honda Code 4743209).
2	28405-ZL0-000ZB	1	SPACER, RECOIL STARTER MOUNTING *R8* (BRIGHT RED) (Honda Code 4743217).
3	28410-ZH8-003ZA	1	CASE, RECOIL STARTER *R8* (BRIGHT RED) (Honda Code 3683869).
3	28410-ZH8-003ZB	1	CASE, RECOIL STARTER *NH1* (BLACK) (Honda Code 4193058).
4	28420-ZH8-013	1	REEL, RECOIL STARTER (Honda Code 4193066).
5	28422-ZH8-013	2	RATCHET, STARTER (Honda Code 4193074).
6	28433-ZH8-003	1	GUIDE, RATCHET (Honda Code 3683893).
7	28441-ZH8-003	1	SPRING, FRICTION (Honda Code 3683901).
8	28442-ZH8-003	1	SPRING, RECOIL STARTER (Honda Code 3683919).
9	28443-ZH8-003	2	SPRING, RETURN (Honda Code 3683927).
10	28461-ZH8-003	1	KNOB, RECOIL STARTER (Honda Code 3683950).
11	28462-ZH8-003	1	ROPE, RECOIL STARTER (NA USE ALT:08550-ZG921-11) (Honda Code 3683968).
12	90003-ZH8-003	1	SCREW, SETTING (Honda Code 3684222).
13	95700-06018-00	3	BOLT, FLANGE (6X18) (Honda Code 0481184).
13	95701-06018-00	3	BOLT, FLANGE (6X18) (Honda Code 2410900).